

Echo

DE-LIME



De-Limer and Metal Brightner

PRODUCT

ECHO-DELIME quickly dissolves and removes lime, rust, iron, milk stone, hard water stains, soap scum, machine dish wash detergent residues from steam tables, ice machines, coffee urns, shower stall, milking machines, faucets, drain boards, steam cleaners, heat exchanges etc.

FEATURES AND BENEFITS

- ECHO-DELIME is a non foaming detergent excellent for the use in spray-type dish washing machines where a non foaming acid detergent is necessary
- Can safely be used in all internal surfaces of dish wash machines
- Cleans stainless steel, aluminum, copper, brass, chrome, ceramic tile, porcelain, plastic, glass, vitreous china and fiber glass
- Removes lime deposits and rust from metal surface

PRODUCT DETAILS

Description	Specification
Appearance	Liquid
Colour	Light green
Nature	Acidic
pH of 1% solution	1.5 - 1.7
Detergency	Excellent
Solubility in water	Completely soluble in water
Specific gravity	1.1-1.2

APPLICATION

ECHO-DELIME quickly dissolves and removes lime, rust, iron, milk stone, hard water stains, soap scum, machine dish wash detergent residues etc. It is also recommended for the delimiting and cleaning of steam tables, ice machines, coffee urns, shower stall, dish washing machines, milking machines, faucets, drain boards, drinking glasses, steam cleaners, heat exchangers etc.

DIRECTIONS FOR USE AND DOSAGE

Dish wash and Glass washers:

Switch on the machine, fill warm water and pour 300 - 500 ml of ECHO DE-LIME directly in to the machine. Give 20 minutes contact time. Conveyer machines add 500-800 ml and rinse the machine two times. For urns and kettles use at the rate of 100 - 150 ml per 5 ltrs and boil. Carefully drain and rinse with fresh water.

INSTRUCTIONS

To ensure the best results, the machines should be regularly serviced and operated in accordance with the manufacture's instructions and recommendations. The washing process will be maximized if utensils can be washed as soon as possible after becoming soiled and the correct detergent concentrate for the level of water hardness is employed.

Atlantic Care Chemicals

3545 Stonecutter Crescent, Mississauga, Ontario, L4M 7N7, Canada
E-mail: care@atlanticchemicals.com / www.atlanticchemicals.com



TECHNICAL SERVICE

Our technical service team is available to assist our customers on the optimum usage of ECHO-DELIME under specific conditions

PACKAGING

4X5 Ltrs Carton.

SHELF LIFE


ECHO-DELIME is stable for up to 12 months from the date of production, when stored in the original unopened container in a dry area without exposure to direct sunlight at temperature up to 25°C.

HEALTH AND SAFETY

Cause severe Irritation and burns to eyes and skin. Harmful if swallowed. Wear suitable gloves and eye face protection. Incase of contact with eyes rinse immediately with plenty of water and seek medical advice. Keep away from heat and live flames.



- Do not Ingest
- Do not pre-mix with other chemicals
- Keep out of Reach of Children



Atlantic guarantees that our products comply with the sales specifications. The information contained in this document is true and reliable and is given in good faith based on our current knowledge. The customers may satisfy themselves (by appropriate testing if necessary) that the product is suitable for their purposes and conditions of use and ensure compliance with local legislation. Users are requested to check that they are in possession of the latest version of this document and we are at their disposal to supply any additional information.

IET 090110/01

January 2012



PASSION FOR INNOVATION

